

---

Format CALL SAMS("OFF")

### Description

SAMS("OFF") command will only work with a SAMS memory card. The read/write lines to the AMS mapper registers are turned off so they will not be changed. Any PEEK or LOAD to the DSR space will be zero after the SAMS("OFF") command. They can't be read/written to. See docs MANUAL-AMS for examples of memory maps.

Also run SAMS-TEST or SAMS-SAVE or SAMS-LOAD programs.

### Programs

This turns on read/write.		>100 CALL SAMS("ON")
This fetches map register 2.		>110 CALL PEEK(16388,BYTE)
This turns off read/write.		>120 CALL SAMS("OFF")
This turns on pass mode.		>130 CALL SAMS("PASS")
This prints the page from map mode in register 2.		>140 PRINT "Register 2 PAGE#" ;BYTE

The above program will print out initialized SAMS page 2 in register 2.

It is recommended that CALL SAMS("OFF") only be used to protect the AMS mapper registers from being molested by programs that could access the AMS. CALL SAMS is more easy to use to manage SAMS memory as SAMS always turns off the SAMS read/write registers like SAMS("OFF") does.